

### Advice from Villeroy & Boch on preparing to install a tap

#### PLEASE NOTE

Examine the sink for damage BEFORE INSTALLATION. Only install a sink that is in perfect condition.

**IMPORTANT!** Always wear protective goggles and suitable protective clothing when knocking out the tap hole

BEFORE INSTALLATION knock out the tap holes required as follows:

- Carefully transfer the centre of the tap hole required from the lower side of the sink onto the glazed upper side and cover with masking tape. This will prevent the drill from slipping. Using a centre punch, crack the glaze in the centre of the required hole and using a No.8 masonry drill, carefully drill from the top a small pilot hole. **ONLY DRILL ONE SMALL HOLE**
- You can then proceed to enlarge the hole to the required size by using your hammer and centre punch carefully.

Please be very careful not to damage the glaze around the tap hole.

If you have any doubts about your ability to carry out this procedure safely and without causing damage, please seek professional help.

